



OPTIMA RS

Temperature Maintenance Tray System

The Best Solution for Room
Service (RS). Hot Food Hot
and Cold Food Cold.

burlodge
TOGETHER, WE WORK.



The Optima RS trolley is an innovative heated and refrigerated food trolley developed to maintain hot and cold food temperatures. The design of the unique single tray system enables the delivery of plated meals on a one piece flat tray.

The **OPTIMA RS** is the result of years of research and development, competitor benchmarking, and over 30 years of industry leading innovation and manufacturing. Burlodge has created the optimal solution for food service professionals.



The **OPTIMA RS** will keep meal components at serving temperature (both hot and cold) during holding in the kitchen, transport, and service.



Compared to traditional induction pellet systems, the **OPTIMA RS** does not require specific tray ware components, specific support equipment, or heavy heated pellets. Moreover, the **OPTIMA RS** keeps food cold without having to add expensive and clunky chill packs or cold base containers.



It is an all-in one solution. Plug it in, load your trays, hold in the kitchen, transport when ready and serve. You can even plug the **OPTIMA RS** in at patient service levels to ensure food is kept hot and cold.





Features

- Multifunction graphic LCD display.
- Mechanical side panel made of anti-static high impact thermoplastic service area for temperature maintenance.
- Optional electrical connection at patient ward.
- Divider wall can be disassembled for deep cleaning, repair, maintenance.
- Magnetic latching doors with access to hot and/or cold sides of tray with easily removable door gaskets.
- Removable tray slides inside the unit to facilitate cleaning and maintenance.
- Ergonomic push handle.
- Four castors, two swivel and two fixed for ease of movement and turns.
- Flat top to help transport other items to and from units.
- Made of 304 18/10 stainless steel and aluminum.
- Access trays from either side of the trolley.
- Electrical connection to kitchen power to gain maximum heating and cooling capability.
- Easy to use controls with automatic start/stop and audible alarm
- Quiet operation.

Options

- Top guard rail.
- Destination name plate holder.
- Tow bar.
- 6 wheel configuration.
- SIS castors.
- Decorative side/front Panels.
- Side shelf.

Optima RS | Short Model

8 Tray Trolley	Each tray has dedicated heating pad.	4 trays per chamber.	160mm tray spacing.
12 Tray Trolley	Heating pads spaced out within each chamber.	6 trays per chamber.	92.3mm tray spacing.
12 Tray Trolley Plus	Each tray has dedicated heating pad.	6 trays per chamber.	92.3mm tray spacing.
16 Tray Trolley	Heating pads spaced out within each chamber.	8 trays per chamber.	80mm tray spacing.

Optima RS | Tall Model

12 Tray Trolley	Each tray has dedicated heating pad.	4 trays per chamber.	160mm tray spacing.
18 Tray Trolley	Heating pads spaced out within each chamber.	6 trays per chamber.	92.3mm tray spacing.
18 Tray Trolley Plus	Each tray has dedicated heating pad.	6 trays per chamber.	92.3mm tray spacing.
24 Tray Trolley	Heating pads spaced out within each chamber.	8 trays per chamber.	80mm tray spacing.

Electrical requirement is 220/240V, Single Phase, 50/60Hz, 16 Amp.

The Burlodge Tray

Meal trays can be seen inside the Optima RS through protective polycarbonate doors. At a glance, users know the status of each of their Optima RS trolleys without having to open doors and peek inside. Inside the Optima RS there is a divider wall that completely separates the hot from the cold side of each tray. The tray simply slides into the divider wall and there is no more handling.



Beige



Green



Lobster

You can use a large style flat tray 575mm x 325mm or you can use a smaller size flat tray 530mm x 325mm.

The Burlodge tray is completely flat without holes or grooves and has been approved by Occupational Therapists as the best type of tray surface for patients suffering from depth perception and spatial orientation challenges.



OPTIMA^{RS}



MANUFACTURER RESERVES THE RIGHT TO CHANGE MATERIAL & SPECIFICATIONS WITHOUT NOTICE

UNITED KINGDOM

Burlodge Ltd
C60 Barwell Business Park
Leatherhead Road
Chessington, Surrey KT9 2NY
United Kingdom
sales@burlodge.co.uk
www.burlodge.co.uk

ITALY & EXPORT

Burlodge Srl
Via Ca' Bertoncina, 43
24068 Seriate, Bergamo
Italy
info@burlodge.it
www.burlodge.it
www.burlodgeexport.com

CANADA

Burlodge Canada Ltd
10 Edvac Drive
Brampton, Ontario L65 5P2
Canada
info@burlodgeca.com
www.burlodgeca.com

USA

Burlodge USA Inc.
P.O. Box 4088, 3760 Industrial Dr.
Winston Salem 27115 - 4088
North Carolina
USA
info@burlodgeusa.com
www.burlodgeusa.com

FRANCE

Burlodge SAS
ZAC Léonard de Vinci
16 Avenue Graham Bell
77600 Bussy Saint Georges
France
accueil@burlodge.fr
www.burlodge.fr

www.burlodge.com

an Ali Group Company



The Spirit of Excellence